

## VECTOR

### VECTOR/RX

The VECTOR/RX system has been purpose designed to satisfy the market request for a security system that protects both the premises and its perimeters.

VECTOR/RX is able to interface between hardwired and wireless burglar systems, and thus finds its niche in installations where the consolidated reliability of hardwired detectors cannot be applied. This innovative product allows the installer to kit-out hybrid burglar systems with a wide range of wireless devices. It supports up to 32 wireless devices (31 for KY032 and KY032G) and 16 keyfobs.

It can be connected to Bentel Security's KY08W, KY08G, KY016D, KY032, KY032G, KY0100 e KY0300, control panels by means of serial bus, or to other brands of control panels by means of the apposite outputs.

The VECTOR/RX is fully compatible with all brands of control panels and offers installers maximum flexibility, and quick and easy installation.

### VECTOR/RX8

Wireless receiver for KY0 security control panel with the same features of VECTOR/RX but with 8 zones.

### VECTOR/BRIDGE

Vector/Bridge is a kit integrating Vector receiver together with a device that allows to connect it to different control panels. equipped with 16 open collector outputs. One of the many interesting features of this product is its memory, that provides information on events such as: low-battery, detector trouble, jamming, and also, information on alarms that occur exclusively during armed status. By means of this detailed information it is possible to expand the initial capacity of small control panels.

## FEATURES

- 8 open-collector outputs for alarms
- 1 open-collector output for tamper
- 1 open-collector output for low battery
- 1 open-collector output for trouble
- 1 open-collector output for jamming
- 4 open-collector outputs for wireless keys
- Double display with 7 segments
- 1 armed/disarmed input
- 1 view and memory reset input
- 12V power supply only in stand-alone

### ACCESSORIES

#### BPI/LINK

Vector serial link



VECTOR/RX 



VECTOR/RX8



VECTOR/BRIDGE

### ORDER CODES

**VECTOR/RX** Wireless receiver 32 zones for KY0 control panel

**VECTOR/RX8** Wireless receiver 8 zones for KY0 control panel

**VECTOR/BRIDGE** Wireless universal interface and receiver for security panels